

1

M I N U T E

INDEXED

STE  
Through SM

SUBJECT :- Printer Switch Box for MARSIK

We need a printer switch box for the MARSIK consoles and error logger. There are 6 consoles and 1 printer so a switch box to perform the function of the attached diagram is required.

At the moment we either have to copy screen down manually or get the engineers to recable the printer. Neither is a satisfactory option.

We will also need 7 cables and the D connector terminators. The cables only need to connect pin (2,3,20,1,7) to pin (2,3,20,1,7) respectively. The dimensions of the box will dictate its location and therefore the cable lengths. Please contact SMC when you need details.

The diagram has an error in that the signal ground (pin 7) should also be switched.

A/SMC  
13/5/86

EXAMINED

M I N U T E

1

# C.I.TOH PRINTER SWITCH BOX

Declassified by ASD - 03/02/2022

ALL SOCKETS ARE FEMALE

